

A.R.M. (USA), INC 1506 Fernwood Rd. Wintersville, OH 43953 740.264.6599 740.266.2953 Fax Bulletin No: SB050216 Release Date: MAY 2, 2016 Effective Date: MAY 2, 2016

Supercedes: N/A

Completion Date: MAY 31, 2016

Page: 1 OF 3

SERVICE BULLETIN

Manufacturer: A.R.M. (USA). Inc. Model(s): VG100, VG200, & VG300

Ride Name: Vertigo Affected Production Dates: 2010-2015

AFFECTED SERIAL NUMBERS

ABSTRACT OF ISSUE

A mandatory requirement to drain and inspect the ride rotational gearbox oil and add an oil expansion tank in combination with maximum oil fill capacity. A.R.M. (USA), Inc. will supply the oil tank kit at no cost. Compliance to begin once the oil expansion tank kit is received. It continues to be recommended that the ride rotational gearbox oil be changed annually, as stated in the ride manual.

REASON FOR RELEASE

To increase service life of internal gearbox components.

ACTION TO BE TAKEN

Upon receipt of this Service Bulletin, phone A.R.M. (USA), Inc. parts department and supply current shipping address. Once the oil expansion tank is received, follow the instructions listed in the Detail of Issue section below.

DETAIL OF ISSUE

Detail of Issue:

- 1. Remove auto vent breather from top side of gearbox and discard;
- 2. Remove a plug from the bottom side of the gearbox and drain existing oil entirely into a clean container;
- 3. Inspect oil for contaminants and for foreign debris. If either are found, consult with A.R.M. (USA), Inc. service department before proceeding:
- 4. Reinstall bottom drain plug;
- 5. Remove top screw plug in area as indicated on drawing. Swap with original auto vent breather location.
- 6. Fill gearbox complete with ISO220 Synthetic Oil (21.5 Liters);
- 7. Install oil expansion tank in location as indicated on drawing.
- 8. Remove breather from top side of oil expansion tank.
- 9. Continue to fill oil through the breather port on the top side of the oil expansion tank until level is indicated half way on lower, large, site glass of oil expansion tank.
- 10. Install breather removed in step 8 into top port of oil expansion tank.

100 SERIES:

VG101-07-01-09 VG102-07-01-10 VG103-05-21-11

VG104-04-01-12

VG105

VG106 VG107

VG107

200 SERIES:

VG201-01-30-10

VG202-03-13-10

VG203-05-01-10

VG204-06-10-10 VG205-08-15-10

VG206-08-15-10

VG207-01-29-11

VG208-06-25-11

VG209-01-05-12

VG210

VG211

VG212

VG213

VG214

300 SERIES:

VG301-03-05-11 VG302-10-01-11

VG303-01-05-12

VG304

VG305

NOTICE

ONLY COMPONENTS SPECIFIED, AUTHORIZED, OR PROVIDED BY A.R.M. (US), INC. SHALL BE USED A.R.M. (US) INC. SPECIFICALLY DISCLAIMS ANY LIABILITY ASSOCIATED WITH THE USE OF UNAUTHORIZED COMPONENTS OR MODIFICATIONS AND/OR ALTERATIONS OF AUTHORIZED COMPONENTS.

EXPANSION TANK KIT INSTALLATION







